

DIRECTIONS

WITH THE ALCOHOL WIPE PROVIDED, THOROUGHLY CLEAN A 3" AREA WHERE YOU WANT TO MOUNT THE CONTROL HOLDER. IN ORDER FOR THE ADHESIVE STICKER TO WORK PROPERLY ON THE VEHICLE INTERIORS, ALL TRACES OF ARMOR ALL™ OR SIMILAR PRODUCTS MUST BE REMOVED ENTIRELY FROM THE MOUNTING AREA. PEEL ONE SIDE OF THE ADHESIVE STICKER PROVIDED. APPLY ADHESIVE STICKER TO AREA YOU CLEANED THOROUGHLY WITH ALCOHOL. PEEL OTHER SIDE OF STICKER AND FIRMLY PRESS THE LARGE SIDE OF HOLDER ONTO THE STICKER.

* DRILL THE SCREW PROVIDED THROUGH THE HOLE ON THE HOLDER. IF SCREW IS NOT USED, LET HOLDER STAND FOR 12 HOURS BEFORE YOU MOUNT THE CONTROL.

