WESTERN PRODUCTS P.O. BOX 245038 MILWAUKEE, WI 53224-9538 28340 HEADLAMP EXTENSION BRACKET KIT


Parts List Installation Instructions

A DIVISION OF DOUGLAS DYNAMICS, L.L.C.

# **A** CAUTION

Read this document before installing the Headlamp Extension Bracket Kit.

#### PARTS LIST AND DIAGRAM




28340 HEADLAMP EXTENSION BRACKET KIT		
Item	Qty	Description
1	1	HEADLAMP EXTENSION BRACKET DS
2	1	HEADLAMP EXTENSION BRACKET PS
3	2	1/2-13 X 1-1/2 HEX CAP SCREW G5
4	4	1/2 FLAT WASHER
5	2	1/2-13 HEX LOCKNUT GB
6	2	5/16-18 X 1 HEX CAP SCREW
7	2	5/16 -18 HEX LOCKNUT GB
		G = GRADE

### INSTALLATION INSTRUCTIONS

## For UniMount® Lift Frame:

There is a short and long version of the existing headlamp mounting brackets on the UniMount® upper lift frame. Before installing the Headlamp Extension Bracket Kit and your new headlamps, replacing the long brackets with the shorter version is recommended.


- Mount the headlamp extension brackets to the headlamp mounting holes in the existing headlamp brackets with a 1/2" x 1-1/2" hex cap screw, 1/2" flat washer and 1/2" hex locknut on each side as shown. Hand tighten.
- Slide the extension bracket on its slot until the tab contacts the top light bracket, and align the front of the brackets to be parallel with the front of the lift frame
- 3. Using the extension brackets as guides, locate and drill an 11/32" hole through the top light bracket on each side. Insert a 5/16" x 1" cap screw and 5/16" hex locknut as shown.
- 4. Tighten all fasteners and mount the headlamps as described in the Mount Headlamps to Extension Brackets section of these instructions.



# **Mount Headlamps to Extension Brackets**

Place the headlamp swivel plate onto the headlamp mounting studs and place the lamp onto the extension bracket. Mount using a 1/2" lock washer and 1/2-13 hex nut on the inside hole of the extension bracket and a 1/2" flat washer, 1/2" lock washer and 1/2-13 hex nut on the outside slotted hole of the extension bracket as shown opposite. Shaded items are included in the headlamp kit.

Headlamps are to be aimed as instructed in the Owner's Manual for the snowplow or in the Headlamp Aiming Instructions found in the headlamp kit.



Copyright © 2005 Douglas Dynamics. L.L.C. All rights reserved. This material may not be reproduced or copied, in whole or in part, in any printed, mechanical, electronic, film or other distribution and storage media, without the written consent of Western Products. Authorization to photocopy items for internal or personal use by Western Products outlets or snowplow owner is granted.

Western Products reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used. Western Products and the vehicle manufacturer may require and/or recommend optional equipment for snow removal. Do not exceed vehicle ratings with a snowplow. Western Products offers a limited warranty for all snowplows and accessories. See separately printed page for this important information. The following are registered (®) trademarks of Douglas Dynamics, L.L.C.: UniMount®, WESTERN®.

#### Printed in U.S.A.