



Adapter Kit 52942-M required for F450 Super Duty								
Item	Part #	Description	MKP B	MKP B- QLII	QL- MK B	QLII- MKB	QLII- HI- MKB	QLII- HI- MKB- TE
12	HH-00457-003	5/8" Lockwasher	2					
14	HH-00460-001	5/8" UNF Hexnut	2					
27	52516-04-B	Support Angle, Curb Side	1					
28	52515-03-A	Support Angle, Driver Side	1					
29	52575-03-A	5/8" x 1.1/2" Cap screw c/w Welded Handle 14"	1					
30	52575-01-A	5/8" x 1.1/2" Cap screw c/w Welded Handle 6"	1					

## INSTALLATION INSTRUCTIONS FOR 52942-M

1. Follow instruction from installation sheet 53061-MKPB.
2. For thrust arm installation, install support angle (27)(28) on inside of the vehicle frame, using 5/8" welded bolt (29)(30), 5/8" nut (14) and 5/8" lock washer (12).
3. Install thrust arms between springs and bottom of frame rail from outside of frame by feeding the bottom of the thrust arm through first. The chassis may have to be raised slightly to permit installation. Secure thrust arm to support angle (27)(28) using ½" x 1.3/4" bolts (25), lock washers (11) and hex nuts (15).
4. Continue installation using 53061-MKPB