

www.storksplows.com
73979 Adapter Kit

Installation Instructions

Plug-In Harness Installation

Follow the Isolation Module Installation Instructions included with the harness kit until directed to use these adapter kit instructions.

Plug-In Adapter Installation

NOTE: Use dielectric grease on all electrical connections to prevent corrosion. Fill receptacles and lightly coat ring terminals and blades before assembly.

Driver's Side

1. Connect a plug-in adapter male connector to the vehicle harness female connector removed from the headlamp. Connect the plug-in adapter female connector to the headlamp.
2. Splice the "TURN" wire from the plug-in adapter harness into the driver-side turn signal wire following the recommended splicing procedure. Splice the "PARK" wire from the plug-in adapter into the parking light wire following the splicing procedure.

Passenger's Side

1. Connect a plug-in adapter male connector to the vehicle harness female connector removed from the headlamp. Connect the plug-in adapter female connector to the headlamp.
2. Splice the "TURN" wire from the plug-in adapter into the passenger-side turn signal wire following the recommended splicing procedure.

Harness Connection

1. Connect both plug-in adapters to the plug-in harness. Be sure to connect the driver-side adapter to the green wire leg of the plug-in harness.
2. Cable tie harness and adapters to existing wiring.

The company reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used. This equipment manufacturer or the vehicle manufacturer may require or recommend optional equipment for snow removal. Do not exceed vehicle ratings with a snowplow. The company offers a limited warranty for all snowplows and accessories. See separately printed page for this important information.

Printed in U.S.A.
