


REF	QTY.	PART NO.	DESCRIPTION
1	1	-	UPPER CASING FOR TOUCH PAD CONTROL
2	1	-	LOWER CASING FOR TOUCH PAD CONTROL
3	5	-	#6 X 3/4 HIGH/LOW SCREW
4	1	62191	TOUCH PAD CONTROL PCB
5	1	62192	KIT, DECAL SB TOUCHPAD W/ADHESIVE PADS

REV.	ZONE	DESCRIPTION	E.C.N. #	BY	DATE
A	-	INITIAL RELEASE	19547	SAG	8/11/03
B	-	CHANGED DESCRIPTION IN ITEM #5	20567	SAG	2/6/04



NOTE: PRINT REPRODUCED FOR BLIZZARD TECHNICAL SERVICE USAGE

DRAWING NAME: BLIZZARD CONTROL ASSY SB-BLADE TOUCHPAD

DRAWN BY: SAG DATE: 8/11/03 CHECKED BY: DATE:

SIZE: B SCALE: FULL SHEET: 1 of 1 DRAWING NO.: 50-3171-00EX REV.: B

DO NOT SCALE DRAWING

BLIZZARD #62142

TOLERANCES ARE:
 FRACTIONS DECIMALS ANGLES
 $\pm 1/32$ XX $\pm .01$ $\pm 0'30$
 XXX $\pm .005$
 UNLESS OTHERWISE SPECIFIED,
 DIMENSIONS ARE IN INCHES.