




VEHICLE UNDERCARRIAGE INSTALLATION INSTRUCTIONS



UNDERCARRIAGE **32167**

HARDWARE KIT **61367**

FOR MODELS:

DODGE DAKOTA (1987-1996)

DODGE DAKOTA SPORT (1997-2003)

DODGE DAKOTA SLT EXTENDED CAB (1997-2003)


DODGE DURANGO SLT (1998-2003)

INSTALLATION INSTRUCTIONS

P/N 32167
PUSH BEAM P/N 32168

08-1501-218

A label identifying the undercarriage assembly part number and push beam part number is applied to the rear of the push beam.



The recommended push beam height for this undercarriage assembly is 10-1/2" from the center of the push beam to level ground. DO NOT exceed 12-1/2" in height for this undercarriage.

WARNING: Always perform vehicle undercarriage installations with the keys removed from the vehicle's ignition. Properly tag the ignition switch to alert others work is being performed on the vehicle.

Most newer trucks are equipped with driver and passenger's side air bags. DO NOT remove, disable, or reposition any sensory equipment related to the safe operation of the air bags.


ALWAYS follow the vehicle manufacturer's recommendations for installing snowplowing equipment.

FAILURE TO COMPLY WITH THE ABOVE WARNINGS MAY RESULT IN SERIOUS INJURY OR DEATH.

CAUTION: If your vehicle is equipped with oversize tires, they may come into contact with the undercarriage hanger plates when turning the vehicle. Adjust steering stops if possible.

1. Disconnect the fog lamp harnesses if applicable. Remove the front bumper and the bumper mount plates, which are located between the frame rails and radiator. Discard the mount plate hardware.
2. Position each hanger plate (**Ref 6**) between the inside of the truck frame rail and bumper mount plate. Align the holes on the plates with the holes in the frame. Secure with bolts (**Ref 8**) and washers (**Ref 7**) through each of the holes. *NOTE: Each hole contains a welded nut on the inside of the truck frame rail. NOTE: The Dakota Sport, Dakota SLT Extended Cab and Durango SLT require bolts (**Ref 9**) washers (**Ref 10**) and nuts (**Ref 11**).* Finger tighten the fasteners until all undercarriage parts are in place.
3. Use a floor jack and position the pushbeam between the hanger plates and in-line with the vehicle crossmember. Secure the pushbeam to the crossmember with t-bolts (**Ref 14**), washers (**Ref 13**) and nuts (**Ref 12**). *NOTE: Remove the access hole covers to help position the t-bolts through the crossmember correctly.*
4. Mount the push beam (**Ref 1**) square with the bottom of each hanger plate using bolts (**Ref 9**), washers (**Ref 10**) and nuts (**Ref 11**). Tighten pushbeam hardware according to torque specifications.
5. Level the pushbeam with the floor and torque the hanger plate and crossmember hardware.
6. Replace the bumper. Reconnect the fog lamp harnesses if applicable.
7. Position the **Light Tower** into the mount pockets on the push beam. Each pocket has a lock pin that secures both light tower arms. Pull out and twist each ring handle to temporarily unlock the pins. Place the light tower into the pockets and relock the pins. Mount each **Plow Headlight** to the light tower with the hardware kit provided.
8. Plug the connectors from the snowplow headlights into the connectors on the vehicle wire harness. Adjust both lights with the plow in the raised position.

UNDERCARRIAGE PARTS



REF	PN	QTY	DESCRIPTION	NOTES
-	32167	1	Asm, Undercarriage	INCLUDES 1-14
-	61367	1	Kit, Hardware GM UC	INCLUDES 7-14
1	32168	1	Weldment, Push Beam	
2	61128	1	Decal, Push Beam 1-1/2" x 9"	
3	61309	2	Ring, Standard Split, 1.48" O.D	
4	61000	2	Spring, Draw Latch Lock Pin	
5	40079	2	Pin, 3/8" DIA. x 1-3/4" SS	
6	32076	2	Plate, Hanger	
7	61162	6	Washer, 7/16" SAE Hardened	
8	61459	6	Screw, 7/16-14 x 1-1/2" HHCS GR8 YZ	
9	61055	14	Screw, 1/2-13 x 1-1/2 HHCS GR8 YZ	
10	61026	28	Washer, 1/2" USS Hardened	
11	61020	14	Nut, 1/2-13 Top Lock Z	
12	61058	2	Nut, 9/16-12 Top Lock Z	
13	61059	2	Washer, 9/16" SAE Hardened	
14	31119	2	T-Bolt, 9/16-12 x 2" HHCS GR8 YZ	

Note: The reference numbers listed identify parts shown in the illustration above. These numbers are specific to this illustration only. Always review the part number given for proper component identification. Blizzard Corporation reserves the right, under its Continuous Improvement Policy, to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications.

HEADLIGHT ADAPTER KIT GUIDE

VEHICLE APPLICATION	HEADLIGHT CONNECTOR	HEADLIGHT DESCRIPTION	HEADLIGHT NUMBERS	ADAPTER KIT
1997-2003 DODGE DAKOTA 1997-2003 DODGE DAKOTA SLT EXT. CAB 1998-2003 DODGE DURANGO SLT	HB5	DUAL RECTANGULAR COMPOSITE HALOGEN	9007, H9007	62012
1997-2003 DODGE DAKOTA SPORT	HB1/HB5	QUAD COMPOSITE HALOGEN BULB	9004, H9004 9007, H9007	62050
1987-1996 DODGE DAKOTA	HB1	DUAL RECTANGULAR COMPOSITE HALOGEN	9004, H9004	62011
	2E	DUAL RECTANGULAR (SMALL) HALOGEN LAMP	HP6545, H6545	62053

Note: Headlight adapter kits are not included with vehicle undercarriages. All headlight adapter kits sold separately.

TORQUE SPECIFICATIONS (For reference only)



Grade Identification Marking for J429-Grade 5 Bolt



Grade Identification Marking for J429-Grade 8 Bolt

Nominal Thread Size	SAE J429 – Grade 5			Nominal Thread Size	SAE J429 – Grade 8		
	Clamp Loads (lbs)	Tightening Torque			Clamp Loads (lbs)	Tightening Torque	
		“Lubricated”	“Dry”			“Lubricated”	“Dry”
1/4-20	2,000	6 ft-lbs	8 ft-lbs	1/4-20	2,850	9 ft-lbs	12 ft-lbs
5/16-18	3,350	13 ft-lbs	18 ft-lbs	5/16-18	4,700	18 ft-lbs	25 ft-lbs
3/8-16	4,950	23 ft-lbs	31 ft-lbs	3/8-16	6,950	32 ft-lbs	44 ft-lbs
7/16-14	6,800	37 ft-lbs	50 ft-lbs	7/16-14	9,600	53 ft-lbs	70 ft-lbs
1/2-13	9,050	57 ft-lbs	75 ft-lbs	1/2-13	12,800	80 ft-lbs	107 ft-lbs
9/16-12	11,600	82 ft-lbs	109 ft-lbs	9/16-12	16,400	115 ft-lbs	154 ft-lbs
5/8-11	14,500	113 ft-lbs	151 ft-lbs	5/8-11	20,300	159 ft-lbs	211 ft-lbs
3/4-10	21,300	200 ft-lbs	266 ft-lbs	3/4-10	30,100	282 ft-lbs	376 ft-lbs
7/8-9	29,435	321 ft-lbs	430 ft-lbs	7/8-9	41,550	454 ft-lbs	606 ft-lbs
1-8	38,600	482 ft-lbs	640 ft-lbs	1-8	54,540	680 ft-lbs	900 ft-lbs



Grade Identification Marking for Metric-Grade 8.8 Bolt



Grade Identification Marking for Metric-Grade 10.9 Bolt

Diameter (mm)	Metric Class 8.8			Diameter (mm)	Metric Class 10.9		
	Clamp Loads (Pounds)	Tightening Torque			Clamp Loads (Pounds)	Tightening Torque	
		“Lubricated”	“Dry”			“Lubricated”	“Dry”
5	1,389	3 ft-lbs	5 ft-lbs	5	1,987	5 ft-lbs	7 ft-lbs
6	1,965	6 ft-lbs	8 ft-lbs	6	2,812	8 ft-lbs	11 ft-lbs
7	2,826	10 ft-lbs	13 ft-lbs	7	4,044	14 ft-lbs	19 ft-lbs
8	3,579	14 ft-lbs	19 ft-lbs	8	5,121	20 ft-lbs	27 ft-lbs
10	5,672	28 ft-lbs	37 ft-lbs	10	8,116	40 ft-lbs	53 ft-lbs
12	8,243	49 ft-lbs	65 ft-lbs	12	11,796	70 ft-lbs	92 ft-lbs
14	11,246	77 ft-lbs	103 ft-lbs	14	16,092	111 ft-lbs	148 ft-lbs
16	15,882	125 ft-lbs	167 ft-lbs	16	21,970	173 ft-lbs	231 ft-lbs
18	19,423	172 ft-lbs	229 ft-lbs	18	26,868	238 ft-lbs	317 ft-lbs
20	24,784	244 ft-lbs	325 ft-lbs	20	34,284	338 ft-lbs	450 ft-lbs